

Teileliste UWO-Matrix



Rewamatic V
(1830106)



Sensor 20m. (1830110)
Sensor 30m. (1830111)
Sensor 40m. (1830112)

Nachspeisebox Matrix

- 1. Schwarz (19200240)
- Grau (19200243)
- 2. UWO Rewamatic V mit Halterung (1830101)
- 3. Digi. Füllstandanzeige Modul (1040141)
- 4. Flusswächter (20400104)
- 5. Übergang 1" IG x 1"AG (004JB1)
- 6. UWO-EVO 3-40 (1840099)

Nachspeiseventil

- 7. m. Verlängerung (1837103)
- 8. Haube EPP (19930437)
- 9. Red. Niippel AG 5/4"x1" (19220316)
- 10. CU Bogen MS ÜM 2 x 1" IG (004JB2)
- 11. Ventil Typ 81MS AG (19220403)
- 12. 2 Wege Ventil MS 2x1" IG Motor und Kugelhahn (1830102)
- 14. T-Stk MS 1"x5/4"x1" AG (004JB7)
- 15. Brauchwasserschlauchleitung ÜM1"xUMB1" (004JB4)
- 16. MS Winkel 1"AG (004JB1)
- 17. Konsole (20460101)
- 18. Wandhalterung (1830110)
- 19. Sensor 20m. (1830110)

Versorgungsstrang

- 20. 10-14 (19450101)

UWO-Water GmbH

Mundenheimerstrasse 71, 68219 Mannheim
Tel: +49(0)621-899.58.120 Fax: +49(0)621-899.58.122
www.uwo-water.de uwo@uwo-water.de